





StyleView Drawer Family:



97-849	97-974
97-849	97-975
97-851	97-976
97-853	97-977
97-862	97-978
97-863	97-979
97-864	97-980
97-865	97-981
97-866	97-982
97-867	97-983
97-868	97-984
97-869	97-985
97-900	97-986
97-901	97-987
97-902	97-989
97-903	97-990
97-970	97-991
97-971	97-992
97-972	97-993
97-973	

Equipment & Accessories Disposal

1. Please dispose of all batteries in accordance with local law.
2. All Electronics should be recycled through an electronics recycler.
3. Remaining plastics and metals can be recycled through a commercial recycler.

See website for more recycling information: www.ergotron.com/en-us/company/environmentally-responsible

www.ergotron.com | USA: 1-800-888-8458 | Europe: +31 (0)33-45 45 600 | China: 400-120-3051 | Japan: japansupport@ergotron.com

© 2024 Ergotron, Inc. All rights reserved.



There may be components that are under pressure. Proceed with caution while disassembling.